




## WITH MANUAL TRANSMISSION

FROM START/IGNITION AND  
START/GLOW PLUG CONTROL



## WITH AUTOMATIC TRANSMISSION

FROM START/IGNITION AND  
START/GLOW PLUG CONTROL

