

Product Specification (Rev. B)

EZ Printer/Copier/Fax Cleaner Sheet



Product Name:	EZ Printer/Copier/Fax Cleaner Sheet	
Item Number:	K2-PCFF5	
Style:	Flat	
Pouch Label:	EZ Pouch	
Inches (H x W):	4.66" x 9.75"	
mm (H x W):	118.36 x 247.65 mm	
Solution:	50% IPA / 50% Deionized Water	
Volume:		
Card Material:	Proprietary Spun-Bond Material	
Card Inches:	8.5" x 11"	
Card (mm):	215.9 mm x 279.4 mm	
Thickness Inches:	0.012 (+0.002/-0.001)	
Thickness mm:	0.305 (+0.051/-0.026)	
Corner Radius:	Square Corners	
Special Features:	N/A	
Packaging:	<u>Inner Pack</u>	<u>Master Casing</u>
Quantity:	5 Cards	100 Envelopes
Labeling:	Labeled Envelope	
Package type:	Solid Bleach Sulfate w/ High Gloss SBS	Corrugated (200 lb Test)
Inches (H x W x D):	6" x 10.75" x .012"	11.375" x 17.625" x 12.625"
mm (H x W x D):	152,4 x 273,1 x .30 mm	288,93 x 447,68 x 320,68 mm
Weight:	.24 lbs	26 lbs
Weight Kilograms:	.11 kg	11.8 kg
Cubic Ft:	N/A	1.46 cf
Cubic Meters:	N/A	.04 m3
Cards per unit:	5 Cards	500 / Carton
UPC Code:	644218120800	
	<u>Palletizing</u>	
Quantity:	40 Master Cartons	
Inches (H x W x D):	62" x 40" x 48"	
mm (H x W x D):	1574,8 x 1016 x 1219,2 mm	
Weight Lbs:	1070 lbs	
Weight Kilograms:	485,78 kg	
Cubic Ft:	68.89 cf	
Cubic Meters:	1.95 m3	
Cards per unit:	20,000 / Pallet	

Product Specification (Rev. B)

EZ Printer/Copier/Fax Cleaner Sheet



Front of Pouch

50/50 IPA

Printer/Copier/Fax Cleaner Sheet



SAFE • QUICK • EFFICIENT

Use whenever you change toner or ink cartridges
Easy to use – sheets run through paper path
Pre-Moistened with 50% IPA Cleaning Solution

- Removes dirt, debris and label adhesives
- Cleans rollers
- Helps extend toner and ink cartridge life

Preventative Maintenance Schedule

Usage	Clean Every
Heavy	2 weeks
Medium	4 weeks
Light	8 weeks

Sheet may not appear dirty after use. Paper dust, oils and other foreign matter carried into your equipment cannot be easily seen on the sheet. It is the removal of this material that improves image quality. Sheet is also designed to help correct output problems and minimize equipment downtime. To avoid re-depositing debris in equipment, use each sheet only once.

US patent # 5,227,226 Caution: Flammable. Contains 50% Isopropyl Alcohol

Laser Printers:

Before opening pouch, determine how to print a blank page on your printer. If your software does not allow blank page printing, put a carriage return or period (.) in the blank document you are printing.

Fax Machines:

Place sheet in document feed and press copy button. For fax print path cleaning, place cleaning sheet in paper tray, insert blank paper into document feed and press copy button.

Inkjet Printers,

Bubble Jet Printers:

Place a cleaning sheet in the paper tray or manual feed section of your printer. Print or form feed a blank page. If you are unable to "print" a blank page, try putting a character in a word processor document and then print it.

Copiers:

Place sheet in the paper tray and make a blank copy.

Dot Matrix Printers:

Remove ribbon cartridge and paper. Unfold sheet and position it in printer or typewriter as you would a normal sheet of paper. Print a page of text. Printing Tips: Perform a printer self-test or print a document from a program. To clean platen: Re-insert sheet, firmly grip both ends together (to prevent movement) and rotate platen knob. Platen will spin against sheet. Dispose of sheet.

If you experience a mis-feed or jam. Although we have tried to accommodate as many of the wide variety of machines on the market as possible, some machines may experience a feed problem. We have found that the following suggestions clear up most of these problems.

- Make certain sheet is fully extended and inserted into feed position.
- Always leave at least one sheet of paper in bottom of paper tray before using sheet.
- If sheet does not feed from the manual position, try feeding from the paper tray.
- If the sheet jams, run it upside down.

Back of Pouch

50/50 IPA

Feuille de nettoyage d'imprimante/Copieur/Telecopieur



SÛRE • RAPIDE • EFFICACE

Utiliser lorsque vous remplacez les cartouches à jet d'encre
Feuille facile à utiliser qui passe par la fente d'insertion ou papier
Feuille préhumectée 50% IPA de solution nettoyante

- Dédouille la saleté, les débris et la colle d'étiquettes
- Nettoie les cylindres
- Aide à prolonger la durée de vie des cartouches d'encre et de toner

Programme d'entretien préventif

Utilisation	Fréquence de nettoyage
Importante	2 semaines
Moyenne	4 semaines
Légère	8 semaines

Il est possible que la feuille ne semble pas sale après usage. La poussière de papier, l'huile et les autres substances étrangères qui se trouvent dans l'appareil ne sont pas toujours faciles à voir sur la feuille. Retirer cette saleté améliore la qualité de l'image. La feuille est également conçue pour aider à corriger les problèmes d'impression et à réduire les temps d'arrêt. Afin d'éviter que les saletés ne se redéposent dans l'appareil, il est recommandé de ne pas réutiliser les feuilles.

Brevet US n° 5,227,226 Avertissement: Inflammable. Contient 50 % Isopropyl Alcohol

Imprimantes laser :

Avant d'ouvrir le sachet, s'assurer d'être en mesure d'imprimer une page vierge avec l'imprimante. Si le logiciel ne permet pas d'imprimer une page vierge, mettre un retour de chariot ou un point (.) dans le document vierge à imprimer.

Télécopieurs :

Placer une feuille dans le dispositif d'alimentation des documents et appuyer sur le bouton de copie. Pour nettoyer le passage des pages d'un télécopieur au laser, suivre les directives ci-dessus pour le nettoyage d'une imprimante au laser.

Imprimantes à jet d'encre et à bulle d'encre :

Placer une feuille nettoyante dans le plateau d'alimentation ou l'introduire manuellement dans l'imprimante, imprimer ou faire passer une feuille vierge. S'il est impossible « d'imprimer » une feuille vierge, essayer de taper une seule lettre dans un traitement de texte et l'imprimer la page.

Photocopieurs :

Placer une feuille dans le plateau d'alimentation manuel de l'imprimante et imprimer une page vierge.

Imprimantes matricielles :

Retirer la cartouche ou ruban et le papier. Déplier la feuille et la placer dans l'imprimante ou la machine à écrire comme si c'était une feuille de papier normale. Imprimer une page de texte. Conseils pour l'impression : effectuer un essai d'impression de l'imprimante ou imprimer un document à partir d'un logiciel. Nettoyage du cylindre : introduire de nouveau la feuille, saisir fermement les deux extrémités en même temps (pour empêcher tout mouvement) et faire tourner le bouton d'entraînement du cylindre. Le cylindre va tourner et glisser contre la feuille. Jeter la feuille.

Si la feuille passe mal ou bloque. Bien que nous ayons conçu ce produit pour convenir au plus grand nombre possible d'appareils sur le marché, il peut arriver que certains appareils connaissent des problèmes d'alimentation. Nous avons constaté que les suggestions suivantes éliminent la plupart de ces problèmes.

- S'assurer que la feuille est complètement dépliée et insérée en position d'alimentation.
- Toujours laisser au moins une feuille de papier dans le plateau avant d'utiliser la feuille.
- Si la feuille n'entre pas bien à la main, tenter de la faire entrer par le plateau d'alimentation.
- Si la feuille se coince, la faire passer à l'envers.

Product Specification (Rev. B)

EZ Printer/Copier/Fax Cleaner Sheet



Envelope Label

50/50 IPA

Printer/Copier/Fax Cleaner Sheet



5 Cleaning Sheets

SAFE • QUICK • EFFICIENT

Use whenever you change toner or ink cartridge. Easy to use – sheets run through paper path. Pre-Moistened with 50% IPA Cleaning Solution.

- Removes dirt, debris and label adhesives
- Cleans rollers
- Helps extend toner and ink cartridge life

Made in the U.S.A

50/50 IPA

Feuille de nettoyage d'imprimante/ Copieur/Telecopieur




5 Feuilles de nettoyage

SÛRE • RAPIDE • EFFICACE

Utiliser lorsque vous remplacez les cartouches à jet d'encre. Feuille facile à utiliser qui passe par la fente d'insertion du papier. Feuille préhumectée 50% IPA de solution nettoyante.

- Déloge la saleté, les débris et la colle d'étiquettes
- Nettoie les cylindres
- Aide à prolonger la durée de vie des cartouches d'encre et de toner

Fabriqué Aux Etats-Unis



6 44218 12080 0